

qc-rotterdam1-report

Øyvind Helgeland

May 2, 2018

Module 0 : Data conversion

Data conversion from GenomeStudio to PLINK format was carried out prior to data delivery.

Module 1 Data preparation

Module 1 prepared data for QC procedures. In the exported data from GenomeStudio, samples were coded using project specific retrieval IDs and non-informative family IDs. Also, no sex information was available.

Information about declared sample sex and pedigree structure provided by MoBa were used to update the dataset.

Markers with poor cluster separation, low 10% GC score and high AA theta deviation were removed. Clustering metrics were provided by the SNP table exported from GenomeStudio.

The array contains some duplicated/triplicated markers. Duplicates/triplicates were removed to avoid potential problems downstream.

Illumina provides a conversion list for converting marker IDs used on the array to rsIDs. In the provided list some markers are named '?'. To avoid duplicate/non-informative IDs, the original chip ID was used in situations where no rsID was available.

Illumina technical markers (assigned to chromosome 0) were excluded and markers with poor clustering were eliminated using metrics available from the variant table exported from GenomeStudio. Problematic markers reported by other consortia were subsequently excluded.

NOTE: All markers in the PAR region were correctly assigned to chr 24, no update necessary.

NOTE: The lab in Rotterdam removed 7710 markers showing poor performance prior to delivery (markers not included in the dataset)

Updating sample IDs:

Samples in: 17949

Samples updated: 17949

Samples not updated: 0

Updating parental information:

Samples in: 17949

Samples assigned one or more parents: 5984

Samples not updated: 11965

Updating sex:

Samples in: 17949

Samples where sex was updated: 17949

Samples not updated for sex: 0

Remove markers by cluster separation < 0.4:

Markers in: 692367

Markers removed: 18154

Markers remaining: 674213

Remove markers by 10% GC score:

Markers in: 674213

Markers removed: 19915

Markers remaining: 654298

Remove markerst by AA theta dev:

Markers in: 654298

Markers removed: 4123

Markers remaining: 650175

Remove duplicated markers:

Markers in: 650175

Markers removed: 480

Markers remaining: 649695

Update SNPs to rsID:

Markers in: 649695

Markers updated: 338017

Markers not updated: 311678

Removed technical markers (chr0):

Markers in: 649695

Markers removed: 1910

Markers remaining: 647785

Module 2 Identify core samples and infere pedigree

In module 2 an ethnically homogeneous core set of samples were identified for use in module 3 (marker cleaning). Marker cleaning requires an ethnically homogeneous sample set in order to facilitate marker cleaning sensitive to ethnic outliers. Initially markers with $MAF > 10\%$ were temporarily removed. Samples with missingness rate $> 5\%$ were permanently removed. Markers with missingness $> 2\%$ were temporarily removed. The resulting dataset was then used to assess and update the sex of samples where reported and genetic sex did not match.

Further, strand-ambiguous markers, non-autosomal markers, and markers with $HWE\ p < 1e-4$ were temporarily removed before IBD estimation.

the dataset was subsequently split into a parent dataset and offspring dataset, the latter including only one child in case of siblings (selected at random). The resulting datasets were cleaned separately in the modules described in the following modules and merged in module 7.

Markers and samples in

Markers in start: 647785

Samples in start: 17949

Temporary removal of markers with $MAF < 10\%$

Markers in: 647785

Markers removed: 415378

Markers remaining: 232407

Permanent removal of samples with missingness $> 5\%$

Samples in: 17949

Samples removed: 207

Samples remaining 17742

Temporary removal of markers with missingness $> 2\%$

Markers removed: 232407

Markers removed: 3879
Markers remaining: 228528

Temporary removal of non-autosomal markers

Markers in: 228528
Markers removed: 8521
Markers remaining: 220007

Temporary removal of markers with HWE $p < 1e-4$

Markers in: 220007
Markers removed: 842
Markers remaining: 219165

Temporary removal of strand ambiguous markers

Markers removed: 219165
Markers removed: 1205
Markers remaining: 217960

Temporary remove markers in high LD

Markers in: 217960
Markers removed: 6338
Markers remaining: 211622

Prune set of markers using `-indep-pairwise 200 100 0.1`

Markers in: 211622
Markers removed: 171386
Markers remaining: 40236

JONAS STUFF...

Removal of pedigree inconsistent samples

Samples in: 17742
Samples for removal: 64
Samples removed: 64
Samples remaining: 17678

PCA after merge with HapMap

Markers after HapMap merge (used for PCA): 20308

Sample selection post PCA

Samples in: 17678
Samples removed after PCA: 785
Samples remaining after PCA: 16893

Split dataset into founders and offspring

Samples in: 16893
Founders: 11316
Offspring: 5577

Founders
Samples removed: 461 Samples remaining: 10841
</div>

****IBD estimation**** Samples in: 11316 Markers in:
647785

****Remove samples with excess accumulated PIHAT:****
Samples in: 11316 Samples for removal: 14 Samples
removed: 14 Samples remaining: 11302

****Remove one in a pair of samples with PIHAT >
0.1:**** Samples in: 11302 Samples for removal: 478

<div class="column-right"> Offspring

Samples in: 5577 Samples for removal: 11 Samples removed: 11 Samples remaining: 5566

****IBD estimation**** Samples in: 5577 Markers in: 647785

****Remove one in a pair of samples with PIHAT > 0.1:**** Samples in: 5566 Samples for removal: 90 Samples removed: 87 Samples remaining: 5479

****Remove samples with excess accumulated PIHAT:****

Module 3 Identify good markers

Founders

Number of markers and samples at start of cleaning:

Samples in start: 10841

Markers in start: 647785

Remove markers with missingness > 10%:

Markers in: 647785

Markers removed: 288

Markers remaining: 647497

Remove individuals with missingsness > 5%:

Samples in: 10841

Samples removed: 1

Samples remaining: 10840

Remove markers with missingness > 5%:

Markers in: 647497

Markers removed: 1417

Markers remaining: 646080

Remove individuals with missingess > 3%:

Samples in: 10840

Samples removed: 19

Samples remaining: 10821

Remove markers with missingness > 2%:

Markers in: 646080

Markers removed: 8322

Markers remaining: 637758

Remove individuals with missingness > 2%:

Samples in: 10821

Samples removed: 18

Samples remaining: 10803

Remove autosomal markers with HWE $p < 1e-7$:

Markers in: 637758

Markers removed: 1659

Markers remaining: 636099

Remove samples with HET excess > 4SD using common autosomal markers (MAF > 0.01)

Samples in: 10803

Samples removed: 1

Samples remaining: 10802

Remove autosomal markers with HWE $p < 1e-6$

Markers in: 636099

Markers removed: 208
Markers remaining: 635891

Remove samples with HET excess $> 4SD$ using rare autosomal markers ($MAF > 0.01$)

Samples in: 10802
Samples removed: 61
Samples remaining: 10741

Remove markers with missingness $> 2\%$:

Markers in: 635891
Markers removed: 3
Markers remaining: 635888

Temporarily remove samples failing sex check (F: 0.2, 0.8):

Samples in: 10741
Samples for removal: 5
Samples removed: 5
Samples out: 10736

Markers into sex clean:

X markers in: 15099
Y markers in: 712
PAR markers in: 564
MT markers in: 126

Remove chrX and PAR markers with HWE $p < 1e-6$ (only female):

Markers (X + PAR) in: 15663
Markers removed: 29
Markers remaining: 15634

Remove chrX marker if any male has at least one heterozygote genotype:

Markers removed: 694
Markers remaining: 635165

Markers after sex clean:

Autosomes markers out: 619387
X markers out: 14404
Y markers out: 712
PAR markers out: 536
MT markers out: 126
TOTAL: 635165

Offspring

Number of markers and samples at start of cleaning:

Samples in start: 5479
Markers in start: 647785

Remove markers with missingness $> 10\%$:

Markers in: 647785
Markers removed: 246
Markers remaining: 647539

Remove individuals with missingness $> 5\%$:

Samples in: 5479
Samples removed: 2
Samples remaining: 5477

Remove markers with missingness > 5%:

Markers in: 647539

Markers removed: 1223

Markers remaining: 646316

Remove individuals with missingness > 3%:

Samples in: 5477

Samples removed: 19

Samples remaining: 5458

Remove markers with missingness > 2%:

Markers in: 646316

Markers removed: 7548

Markers remaining: 638768

Remove individuals with missingness > 2%:

Samples in: 5458

Samples removed: 9

Samples remaining: 5449

Remove autosomal markers with HWE $p < 1e-7$:

Markers in: 638768

Markers removed: 974

Markers remaining: 637794

Remove samples with HET excess > 4SD using common autosomal markers (MAF > 0.01)

Samples in: 5449

Samples removed: 4

Samples remaining: 5445

Remove autosomal markers with HWE $p < 1e-6$

Markers in: 637794

Markers removed: 123

Markers remaining: 637671

Remove samples with HET excess > 4SD using rare autosomal markers (MAF > 0.01)

Samples in: 5445

Samples removed: 34

Samples remaining: 5411

Remove markers with missingness > 2%:

Markers in: 637671

Markers removed: 5

Markers remaining: 637666

Temporarily remove samples failing sex check (F: 0.2, 0.8):

Samples in: 5411

Samples for removal: 2

Samples removed: 2

Samples out: 5409

Markers into sex clean:

X markers in: 15251

Y markers in: 712

PAR markers in: 564

MT markers in: 126

Remove chrX and PAR markers with HWE $p < 1e-6$ (only female):

Markers (X + PAR) in: 15815

Markers removed: 25
Markers remaining: 15790

Remove chrX marker if any male has at least one heterozygote genotype:

Markers removed: 477
Markers remaining: 637164

Markers after sex clean:

Autosomes markers out: 621013
X markers out: 14774
Y markers out: 712
PAR markers out: 539
MT markers out: 126
TOTAL: 637164

Module 4 : Individuals for analyses

Founders

Markers and samples at beginning of module:

Markers start: 635165
Samples start: 11316

Remove markers not surviving QC in both parents and offspring:

Markers in: 635165
Markers removed: 427
Markers remaining: 634738

Remove samples with missingness rate > 2%:

Samples in: 11316
Samples removed: 42
Samples remaining: 11274

Remove samples with HET excess > 4SD using common autosomal markers (MAF > 0.01):

Samples in: 11274
Samples removed: 1
Samples remaining: 11273

Remove samples with HET excess > 4SD using rare autosomal markers (MAF < 0.01):

Samples in: 11273
Samples removed: 65
Samples remaining: 11208

Remove samples with excess accumulated PIHAT:

Samples in: removed 11208
Samples removed: 11
Samples remaining: 11197

Remove one in a pair of samples with PI_HAT > 0.1:

Samples in: 11197
Samples removed: 457
Samples remaining: 10740

Offspring

Markers and samples at beginning of module:

Markers start: 637164

Samples start: 5577

Remove markers not surviving QC in both parents and offspring:

Markers in: 637164

Markers removed: 2426

Markers remaining: 634738

Remove samples with missingness rate > 2%:

Samples in: 5577

Samples removed: 33

Samples remaining: 5544

Remove samples with HET excess > 4SD using common autosomal markers (MAF > 0.01):

Samples in: 5544

Samples removed: 4

Samples remaining: 5540

Remove samples with HET excess > 4SD using rare autosomal markers (MAF < 0.01):

Samples in: 5540

Samples removed: 38

Samples remaining: 5502

Remove samples with excess accumulated PIHAT:

Samples in: removed 5502

Samples removed: 7

Samples remaining: 5495

Remove one in a pair of samples with PI_HAT > 0.1:

Samples in: 5495

Samples removed: 86

Samples remaining: 5409

Module 5: Preparation for phasing and imputation

Samples and markers into module:

Samples in: 17742

Markers in: 647785

Remove markers not passing QC for both offspring and founders:

Markers in: 647785

Markers shared: 634738

Markers removed: 13047

Markers remaining: 634738

Remove markers above chr 23:

Markers in: 634738

Markers removed: 1374

Markers remaining: 633364

Set mendelian errors to missing:

Mendelian errors zeroed: 186590

HRC harmonizing:

Markers in: 633364

Marker chromosomes changed: 0
Marker positions changed: 0
Marker strand flips: 37109
Marker allele flips: 575573
Markers excluded (not in HRC): 65089
Markers after exclusion: 568275

Number of markers per chromosome sent to phasing:

Chromosome

Number

1	45268
2	46161
3	38636
4	35311
5	33424
6	39844
7	31182
8	29286
9	24176
10	28150
11	28293
12	27051
13	19613
14	18290

15
17219
16
18758
17
17044
18
16219
19
13131
20
13854
21
7705
22
8191
X
11469